

Thank you for purchasing this

**velex**

**VX760R Wireless Remote**

## ① Surface Mount

The VX760R base can be fixed at any convenient position with the 3M tape included in the package.


**Note** that the direction of the arrow points upwards.

The remote can be removed for recharge by turning counterclockwise. After recharge, please rotate the remote clockwise, fix the remote back to base.




## ② Caution

Remote needs to be charged once a year, 5V DC Input (Type C). Suggest to use power bank with 5V output to recharge the remote. The green charging indicator (button ►► ④) will go out when the remote is fully charged.



## GETTING TO KNOW YOUR VX760R MULTIFUNCTION CONTROLLER (MFC)



- ① PREVIOUS TRACK / FAST REWIND
- ② NEXT TRACK / FAST FORWARD
- ③ VOLUME UP
- ④ VOLUME DOWN
- ⑤ SRC-POWER ON/OFF,  
SWITCH AUX IN / BT  
MODES (GREEN LED INDICATION)
- ⑥ PLAY / PAUSE
- ⑦ MFC-MULTIFUNCTIONAL  
CONTROLLER

To pair remote to VX760/VX760D, switch off the head unit, press and hold volume up and down buttons on the remote until display light up with 'REMOTE PAIRED', then VX760R is ready to work.